



Seminary Ridge

Architectural Conservation District
GUIDELINES

Adopted February 2013

TABLE OF CONTENTS

Section I: Purpose	3
Section II: District Principles and Goals	3
SECTION III: Historic Significance, Boundary Description, Period of Significance and Design Characteristics	4-7
Boundary Map	6
Section IV: Administration	7-8
Section V: Guidelines for New Construction	9
New Outbuildings	10
Materials, Textures and Details	10
Section VI: Additions	11
Section VII: Rehabilitation and Maintenance	11
Doors	12
Windows	12-13
Roof Pitch/Material	14
Exterior Siding	14-15
Porches	16
Section VIII: Driveways and Parking Areas	17
Section IX: Business Signage	17-18
Section X: Energy Efficiency	18
Section XI: Relocation	19
Section XII: Demolition	19-20
Section XIII: Definitions	21-22

The Seminary Ridge Neighborhood has requested that the City of Columbia designate their neighborhood as a historic district in 2012. After a survey of every building in the area and a series of public meetings, the following guidelines were drafted, with input from the neighborhood residents and property owners. The City is able to provide professional oversight of their historic districts because of an educated staff of employees who specialize in historic preservation. The addition of this neighborhood as one of the city's protected areas will help foster the continued appreciation of Columbia's unique history as told through its historic homes, neighborhoods, and landmark buildings.

SECTION I: PURPOSE


Design Guidelines are criteria and standards that the Design/Development Review Commission (D/DRC) must consider in determining the appropriateness of proposed work within a historic district. Appropriateness of work must be determined in order to accomplish the goals of historic zoning, which are:

- Protect the beauty of the City and improve the quality of its environment through identification, recognition, conservation, maintenance and enhancement of areas, sites and structures that constitute or reflect distinctive features of the economic, social, cultural or architectural history of the city and its distinctive physical features;
- Foster appropriate use and wider public knowledge and appreciation of such features, areas, sites, and structures;
- Resist and restrain environmental influences adverse to such purposes;
- Encourage private efforts in support of such purposes; and
- By furthering such purposes, promote the public welfare, strengthen the cultural and educational life of the city, and make the city a more attractive and desirable place to live and work.

SECTION II: DISTRICT PRINCIPLES AND GOALS

- Preserve intact historic structures which are part of the history and development of the area;
- Maintain residential patterns in the district;
- Encourage new residential development which enhances the existing neighborhood

Guidelines are not intended to restrict creativity but to guide development in ways that maintain the character of the area and discourage those elements which may threaten it.




SECTION III: HISTORIC SIGNIFICANCE, BOUNDARY DESCRIPTION, PERIOD OF SIGNIFICANCE AND DESIGN CHARACTERISTICS

HISTORIC SIGNIFICANCE


Seminary Ridge is a residential neighborhood surrounded by several major vehicular thoroughfares and historic landmarks, with a landmark building (Ensor-Keenan House) from the late 1800s, and other landmark buildings such as the old Eau Claire Town Hall and the Eau Claire Print building. Located just above the nucleus of the small town of Eau Claire, which developed in the early 1900s, this neighborhood has evidence of its early development as well as continued infill throughout the early and mid-twentieth century. The Lutheran Seminary along its east border has also heavily influenced the landscape and development of the neighborhood.

The capital city of Columbia was expanding rapidly in the early twentieth century. The vehicle age was dawning, and trolley cars were able to move large groups of people rapidly to the outlying suburbs located to the southeast and to the north of the city's historic borders. Land developers saw the trolley lines as paths to wealth, and soon began buying up large tracts of land to create new neighborhoods along the tracks. Frederick Hargrave Hyatt was one such developer. An agent and eventually area manager for the New York Life Insurance Company, as well as a dairy farmer, Hyatt purchased a home north of Columbia in the early 1890s. He began the development of Hyatt's Park and created several neighborhoods, selling off lots at auction and encouraging the growth of the area. He helped establish an electric railway line out to his developments in 1896. Hyatt donated land to Columbia College, and was a dynamic force for developing the small town of Eau Claire, which was incorporated in 1899 with over 200 residents. The town's boundary was in the shape of a circle, with its center at the intersection of North Main Street and Monticello Road.



The new town gained some significant buildings in the late 1890s and early 1900s. The Hyatt Park Pavilion, built in 1897, provided an entertainment center with a casino, vaudeville theater, and orchestra and even a zoo. The next year the Hyatt Park School was completed. The Columbia College moved up from their downtown location to their new property in Eau Claire, and broke ground in 1905. The Lutheran Seminary constructed its first large building in 1911, and in the midst of all the new activity, homes and churches were also being built throughout the area, including Eau Claire Presbyterian Church in 1912, St. Paul Baptist Church in 1911, The Lutheran Church of the Ascension, completed in 1913, and others. While the churches were wood framed, wood-sided buildings, the schools were generally masonry buildings with imposing facades, lending a sense of stability to the new town. Its independence was somewhat brief, however, as the City of Columbia incorporated a portion of Eau Claire in 1913, along with suburbs located east southeast of the city, including Shandon, Waverly and South Waverly.

The area that is now the neighborhood of Seminary Ridge is located in between the two major thoroughfares within Eau Claire, being the two roads whose intersection formed the centerpoint of the town. Just north of the intersection, the ornately decorated brick American Lutheran Survey building, later the Eau Claire Town Hall, was completed in 1914, followed later by the Survey Publishing Building. North of these buildings the neighborhood of Seminary Ridge begins, and residences have remained along this southern border since around the 1920s. Originally, the neighborhood's southern border created a narrow point at the town's center. A plat map



from 1910 indicates that the Monticello Home Company owned the entire area forming a triangle between North Main Street, Ensor and Arlington (west boundary) and Calhoun Street (later Timrod Street), excluding the Lutheran Seminary campus. The Ensor-Keenan House, reportedly built in the late 1860s and rebuilt in 1891 after a fire, was on part of the west boundary of the neighborhood. The company hired an Ohio landscape engineer to draw up the plan, and his plat shows there were to be fairly regularly sized lots, with sidewalks and trees lining the streets. Monticello was the name of the new neighborhood, and playing on the presidential theme it evoked, original street names included Mt. Vernon and Jefferson (later changed to Calhoun, and changed again to Timrod).


The earliest homes in the area were built adjacent to each other on Muller Avenue, by the Cannon family. Though somewhat altered, these homes remain. Churches and the Lutheran Seminary also began building in the area during the early 1900s, with the addition of the Lutheran publishing building by the 1910s. Built of stone and brick, these substantial new buildings offered the town a sense of permanence and stability. The City of Columbia annexed part of Eau Claire in 1913, with the remainder annexed in 1955. Between those periods the neighborhood continued to gain new houses. Bungalows built during the 1920s appear concentrated in the southern part of the neighborhood, along Jackson, Duke and Hillcrest Avenues, as well as their western border, Ensor Avenue. The Great Depression brought construction nearly to a halt, though a few buildings were added along North Main Street, Arlington, Wildwood and Sycamore. Construction picked up during the 1940s and 1950s, with homes filling in along Sycamore, Wildwood, and Ensor Avenue. Timrod gained some homes during the 1950s and 1960s, though its hilly topography seemed to deter consistent development. Reportedly in 1961, President John F. Kennedy tried to boost the steel industry with the re-introduction of steel houses, with seven buildings being built across the nation. One of them is on Timrod Street, and it is strikingly similar to the all-metal Lustron homes created during the 1940s.

The Lutheran Seminary reportedly housed professors in homes in the neighborhood and has undoubtedly contributed to the neighborhood throughout the years. It's campus has created somewhat of a calming buffer between the neighborhood and busy North Main Street. The campus extended into the neighborhood in the late 1990s when it removed all of the homes on Hillcrest Avenue to build student housing. As a result, Hillcrest Avenue no longer exists. There are a few vacant lots in the neighborhood that have been filled in with new housing within the past decade or so, but generally the area retains much of its historic buildings and wide, peaceful streets.

BOUNDARY DESCRIPTION

The west boundary generally follows the east side of Monticello Road up to the Ensor-Keenan House, and west sides of the lots along the west side of Arlington Street. The north boundary is generally along the north property lines of the lots on the north side of Timrod Street, then travels southeast along Fuller Avenue before cutting west along the south property lines of houses on the 1200 block of Sycamore Avenue. The boundary travels north along Hyatt and then west on the 1100 block of Sycamore before heading south behind lot lines along the east side of Kinderway Avenue. The boundary extends west from there along Wildwood Avenue before traveling south, where it undulates along the east side of Arlington Street, before heading west along Jackson Avenue, the southernmost border. This boundary generally follows the 1910 plat for the Monticello neighborhood and includes some development along Monticello Road that was simultaneous with the growth of the neighborhood.

PROPOSED BOUNDARY MAP




PERIOD OF SIGNIFICANCE

The period of significance is from 1910 to 1965, which encompasses the many decades of development that occurred slowly in this neighborhood. This period covers the initial 1910 planned neighborhood from the Monticello Home Company, through the Bungalow and Minimal Traditional and Ranch style homes and is extended through the mid-1960s to include some exceptional examples of mid-century architecture, including an extremely rare all-steel house.

DESIGN CHARACTERISTICS

This is a somewhat eclectic neighborhood given its long period of significance. Early homes from the 1910s have wood clapboard siding and tall roofs, originally clad in standing seam metal. These vernacular homes are concentrated on Muller Avenue. Since development occurred very slowly in the neighborhood, there are only a few of these examples. By the 1920s, Bungalow styles with wood siding and low-slung, varied rooflines and exaggerated porch columns became the norm. Brick siding took over as the dominant exterior building material by the 1930s and 1940s with the influx of the Minimal Traditional styles houses, and continued into the 1950s through the 1960s with Ranch homes. An experimental all-steel house on Timrod is a unique feature of the neighborhood, and a stone-veneered modern house on Wildwood Avenue offers another unique example. Many brick homes feature stucco or other siding in gables, and cast stone or stone is used as a decorative feature around doors. While there are a number of porches, many of them on the sides of buildings, there are also a generous number of stoops in this neighborhood.

There is an unusually diverse and interesting collection of original front doors in this neighborhood, and many of the homes also retain original wood windows, with varying designs, each of them complementary to the architecture of the building. Streets are generally wide and there are only a few sidewalks. There are generally no curbs. Driveways are generally concrete, though there are a few examples of gravel or other materials. Most front yards feature concrete sidewalks, and the homes are all oriented to the street generally parallel to the street; a number of old wire fences and some concrete block, piled stone, and other materials form a few low walls in the area.



SECTION IV: ADMINISTRATION

The city staff in the historic preservation office administers the projects within historic districts, and directs those projects through the review process to the Design/Development Review Commission (D/DRC). When you are planning a project, it is helpful to go ahead and contact the city staff about the work before you make purchases or hire contractors, since the project may require review and/or alterations to help it meet these guidelines. Staff can speak with you, answer questions, visit the site of the project, and look at your plans with you to identify areas that appear to meet or not meet the guidelines.

If necessary, Staff will provide you with an application to appear in front of the D/DRC, which is made up of a group of volunteers with professional backgrounds and interest in design and preservation issues, and which meets once a month to review projects. Once a signed application is returned, your project will be placed on the agenda for the next available meeting. Applying for a building or zoning permit also triggers review by the historic preservation office, so speaking with staff before you make the trip to apply for a permit will help you save time, as we can explain the review process, write memorandums to the permit offices if your project does not require review, and stay in contact with other city staff to help make sure your wait time is minimal.

D/DRC Meetings

If your project does require review by the D/DRC, their meetings are held at 4:00pm, typically on the second Thursday of the month. A blue sign will be placed in your yard 15 days prior to the meeting; it is a simple legal notification for the public hearing. Staff will remove the sign, often the day after the meeting.

At the D/DRC meeting, the staff will present the projects as they appear on the agenda and will usually have photos or plans for the project up on a screen. They will have already prepared an evaluation of your project the week before, showing how it does or does not meet the guidelines. You will be given an opportunity to speak to the D/DRC about your project and answer any questions they may have. Typically, the project is decided that same day, and the next work day the staff will prepare a Certificate of Design Approval if your project was approved. This will allow you to pull the proper permits. If your project was not approved, then you may revise the project and reapply, or you may appeal the decision to circuit court.

Bailey Bill

The city staff is aware that renovation work on historic houses can be costly, and for large-scale projects that are retaining original features and materials for the building, you may be interested in a tax program we offer called the “Bailey Bill.” This program requires that you meet certain parameters, but if you qualify, then the property’s tax value will remain at it’s pre-rehabilitation rate for 20 years, which can be a significant incentive.

A. ACTIONS THAT REQUIRE DESIGN REVIEW

- Additions/Enclosures visible from the public right-of-way
- New construction (includes outbuildings and carports)
- Actions that alter the exterior appearance of a building or remove original materials or features of a building
- Driveways and parking areas
- Signage
- Demolition or relocation (does not include outbuildings)
- Screening Porches (typically reviewed by Staff)

B. ACTIONS THAT DO NOT REQUIRE REVIEW

- Painting and Color (wood siding and trim only; other materials, such as masonry and metal are reviewed if being painted for the first time)
- Work not visible from the public right-of-way
- Interior work
- Fences and walls
- Shutters
- Sidewalks
- Exterior changes to outbuildings
- Demolition of outbuildings
- Awnings and canopies
- Screen doors/storm doors/security doors
- Storm windows

C. GENERAL MAINTENANCE AND REPAIR

If you are repairing or replacing materials on the exterior of the building with the same materials (wood for wood, same size and details), please notify us so that we can notify the Zoning Department that further review from our office is not necessary. The Zoning Department handles simple permits, and you may call them at 545-3333 to ask whether your project requires one.

D. REVIEW OF NON-CONTRIBUTING BUILDINGS

These are buildings that generally are outside of the period of significance for the neighborhood or have had significant alterations to the historic form or details, so that they no longer contribute to the character of the neighborhood. While these buildings are still reviewed under the guidelines, they are most often reviewed at Staff level, with the intent of the review to keep the building architecturally consistent with its own character, materials and period of construction.

SECTION V: GUIDELINES FOR NEW CONSTRUCTION

Seminary Ridge has a few empty lots and has had some new construction in recent years that has generally blended with the overall sizes and shapes of buildings in the neighborhood. The guidelines for new construction are from the city ordinance and are the same for all historic districts. These are intended to help guide new development so that it complements surrounding historic buildings and streets rather than detracting from them. These will also help the neighborhood as it changes over time, so that new buildings maintain some of the essential characteristics of the area, such as the setback of buildings from the street, their general heights, forms and other details.

- (1) Height: Construct new buildings to a height that is compatible with the height of surrounding historic buildings.
- (2) Size and scale: The size and scale of a new building shall be visually compatible with surrounding buildings.
- (3) Massing: Arrange the mass of a new building (the relationship of solid components [ex. walls, columns, etc.] to open spaces [ex. windows, doors arches]) so that it is compatible with existing historic buildings on the block or street.
- (4) Directional expression: Site the entrance of the building so that it is compatible with surrounding buildings.
- (5) Setback: Locate the new building on the site so that the distance of the structure from the right-of-way is similar to adjacent structures.
- (6) Sense of entry: Place the main entrance and the associated architectural elements (porches, steps, etc.) so that they are compatible to surrounding structures. The main entrance shall be constructed with covered porches, porticos, or other architectural forms that are found on historic structures on the block or street.
- (7) Rhythm of openings: Construct new buildings so that the relationship of width to height of windows and doors, and the rhythm of solids to voids is visually compatible with historic buildings on the block or street. Maintain a similar ratio of height to width in the bays of the façade.
- (8) Roof shape: Use roof shapes, pitches, and materials that are visually compatible with those of surrounding buildings.

9. Construction of New Outbuildings

There are a number of historic garages, sheds and detached carports in this district, most of which complement the houses nearby. A majority of them are set back from the house in the back yards, have front gable roofs, and have either wood siding or brick exteriors; a few later examples have concrete block walls.

Guidelines:

1. Outbuildings should reflect the character of the existing house and be compatible in terms of height, scale and roof shape.
2. Outbuildings should be placed away from the primary façade of the building.
3. They should not obscure character-defining features of the building.

10. Materials, Texture, Details: Materials, textures, and architectural features shall be visually compatible with the scale, placement, profile, and relief of details on surrounding structures on the block or street. The D/DRC may evaluate other materials based upon their compatibility within the district, the block on which the structure sits, and the materials found therein. Vinyl siding is an allowable cladding material for new buildings, provided it mimics historic wood siding found in the area. Vinyl windows are allowed on new buildings (not additions), provided they mimic details of historic wood windows, such as dimensional muntins on the exterior of the glass.



SECTION VI: ADDITIONS

A. PRINCIPLES

It is often necessary to increase the space of a building in order for it to continue to adapt to the owner's needs. Over time, a family's space needs change and, in order to accommodate these needs, a building may need to be enlarged. While these additions are permitted, they should serve to reinforce and not detract from the existing architectural form and design of the building.

Additions should not significantly alter original distinguishing qualities of buildings such as the basic form, materials, fenestration, and stylistic elements. Additions visible from the street should be constructed so that the essential form and integrity of the original building will be readily comprehended. Additions should be attached to the rear or least conspicuous side of the building. They should be compatible with yet distinct from the original portions of building and should result in minimal aesthetic damage to it.

Character-defining features of the existing building should not be radically changed, obscured, damaged, or destroyed in the process of adding new construction. They should be constructed so that if visible from the street, the essential form and integrity of the building will be unimpaired.

B. GUIDELINES

1. The most appropriate location for an addition is the rear of the building.
2. Site additions so that they do not detract from or obstruct important architectural features of the existing building or others around it, especially the principal façade.
3. Additions should be compatible with the original structure in materials, style and detailing, but should be distinct from the original building.
4. The size and scale of the new addition should be in proportion to the existing portion of the building and clearly subordinate to it, so that the integrity of the original structure is not compromised.
5. Additions are also subject to the guidelines for new construction.



SECTION VII: REHABILITATION AND MAINTENANCE

PRINCIPLES

Historic buildings often host a variety of owners over the years, each with individual tastes. Buildings also age and need repair or upkeep after a number of years; paint has to be reapplied, old window putty replaced and roof shingles replaced. When projects move beyond normal maintenance to rehabilitation and renovation, it is important that those items visible from the public right of way ensure the preservation of a building's character-defining features, while accommodating an efficient contemporary use.

GUIDELINES

Original materials, textures and details should be retained. Use materials, textures and features that are compatible with the building's original features when repairing or replacing a feature. Replacement of an original feature should only occur when 50% or more of the feature is missing or deteriorated *beyond repair*.

2. DOORS


A. PRINCIPLES

Significant features such as doors and entrances should be preserved wherever possible. Changes to door size and configuration should be avoided. Replacement doors should either match the original or substitute new materials and designs sympathetic to the original.

Sometimes new entrances are required for practical reasons or to satisfy code requirements. Placement of new entrances on principal façades should be avoided. New entrances can result in loss of historical fabric and detailing and change the rhythm of bays. New entrances should be compatible with the building and be located on side or rear walls that are not readily visible from the public right-of-way. If a historical entrance cannot be incorporated into a contemporary use for the building, the opening and any significant detailing should, nevertheless, be retained.

B. GUIDELINES

1. New openings should be installed so that they carry on the same rhythm of existing openings and are compatible in size, materials and design.
2. Historical door openings, doors, trim, and other details surrounding or creating the door and entry such as materials, recessed entries, arches and other shapes should be retained and repaired. Any muntins on glass should be on the outside of the glass.
3. Missing or deteriorated doors should be replaced with doors that visually match the original, or that are of compatible design for the date of the building; they do not need to match historic materials, but may need to be painted in order to match the appearance of a historic door.
4. New entrances on secondary elevations should be placed away from the main elevation. Non-functional entrances that are architecturally significant should be preserved.



3. WINDOWS

A. PRINCIPLES

Wonderful avenues for glimpses of the outside, for natural ventilation and for natural light, windows offer a lot of advantages for our homes. Historic windows offer even more benefits, they were built to complement the architecture of the house, they used old, slow growing wood with natural density and disease and rot resistance, and they were created to be almost infinitely repairable. The windows in Seminary Ridge offer a lot of variety between houses, but for each home they were obviously carefully selected to match the architecture of the home. Created for just a few decades in the early 1900s, some of these styles have never been repeated. Modern materials attempt to replicate the details of these old windows, but they often fail to evoke the character and solidarity of the original windows. If sticking windows are a problem, or the windows simply won't open, the culprit is often the build up of many layers of paint. A simple hand tool can easily remedy this situation in just a few minutes. Consider your historic preservation staff with the City a resource for assessment of your windows and free tips for repair.


Repair

Windows are a significant character-defining feature of any structure. Original windows were constructed so that individual components could be repaired instead of requiring wholesale replacement if one piece breaks or rots. This often means that an existing historical window will be cheaper to repair than to replace. Additionally, materials in historical windows tend to be of better quality than anything available today. The following qualities of the original window must be carefully considered and rigorously applied when repairing windows in order to maintain visual consistency between new and existing window components:

trim detail;
pane size, shape of frame, sash;
location of meeting rail;
reveal or set-back of window from wall plane;
materials, reflective qualities of glass;
glazing
muntin, mullion profiles, configuration.

Replacement of a Window

If, after careful evaluation by city Staff, 50% or more of a window is deteriorated or missing, it should be replaced rather than repaired. Small differences between replacement and historical windows can make big differences in appearance and insulation. The qualities of the original window listed above should also be taken into consideration when replacing a window.



Replacement of Multiple Windows

If more than 50% of the fenestration visible from the street is rotted or beyond repair, then replacement of all existing windows is permitted. However, to ensure visual consistency, it is suggested that if replacing more than 50% of existing windows, replacement windows and windows contiguous to them should reflect the same pattern, design, detailing, etc. If all of the existing windows are being replaced then they should reflect the details of the original windows or of windows from the same period of construction.

B. GUIDELINES

1. When technically and economically feasible, repair of deteriorated or damaged windows shall be preferred over replacement.
2. If replacement of a small number of units is deemed necessary after evaluating the sill, frame, sash, paint and wood surface, hardware, weather-stripping, stops, trim, operability, and glazing, replace with units that match the original in detailing, size, reflective quality, and materials.
3. If wholesale replacement is found to be necessary, either match the original unit or substitute a unit appropriate to the house's period of significance, maintaining the use of historical materials.
4. Improve the thermal performance of existing windows and doors through adding or replacing weather stripping and adding storm windows which are compatible with the character of the building and which do not damage window frames.



4. ROOF PITCH/MATERIAL

A. PRINCIPLES

Roofs are highly visible components of historical buildings. They are an integral part of a building's overall design and often help define its architectural style. The most common residential roof types are gable, hip, or a combination. The original shape and pitch of the roof should be retained. Where existing roofing material is non-original, the existing roof may be retained, replaced in a manner known to be accurate based on documentation or physical evidence, or treated in a material appropriate for the building's period of significance.



B. GUIDELINES

1. The original roof form should be preserved in the course of rehabilitation.
2. Historical roofing materials should be preserved when technically and economically feasible.
3. Deteriorated roof surfacing should be replaced with new material, such as composition shingles or tabbed asphalt shingles, or may be replaced with a material and appearance appropriate to the building's period of construction.
4. The following should be retained and repaired, or replaced only when necessary: dormers, cupolas, cornices, brackets, eaves, exposed rafter tails in eaves, chimneys, cresting, and other distinctive architectural or stylistic features that give a roof its essential character.
5. Rooftop additions are another common change to historical buildings. The addition should be designed to be distinguished from the historical portion of the building yet visually compatible; be set back from the wall plane; and be placed so it is inconspicuous when viewed from the street.



5. EXTERIOR SIDING

A. PRINCIPLES • MASONRY

Masonry features such as cast stone detailing, surface treatments, modeling, tooling, bonding patterns, joint size and color are important to the historical character of a building and must not only be kept in good repair, but retained as close as possible to the original in any restoration or rehabilitation.

While masonry is the most durable historical building material, it is also the most susceptible to damage by improper maintenance or repair techniques or abrasive cleaning methods. Sandblasting and other abrasive cleaning methods are specifically prohibited. Sandblasting not only changes the visual qualities of brick, it damages or destroys the exterior glazing, increasing the likelihood of rapid deterioration of the brick and water damage to the interior of the building. Painting historical masonry is an important concern and not to be undertaken without due consideration for the historical appearance of the neighborhood. The color of masonry, particularly brick, is often an important part of the character of a building. In addition to color, the bonding pattern, treatment of mortar joints, and texture are significant parts of brick buildings. Where brick and other masonry finishes were unpainted, they should generally remain so. Painting obscures detailing and alters the distinguishing original qualities of a building. Under some circumstances, particularly where the brick quality is poor or abrasive cleaning methods have been used, painting brick may be appropriate as a protective measure.

B. PRINCIPLES • WOOD

Where original wood siding exists on a structure, it should be retained. If it becomes necessary to replace deteriorated boards, match the replacements to the characteristics of the original. Important characteristics of wood siding that should be considered in its repair or replacement are board size, width of exposure, length, and trim detail such as corner boards.

One of the greatest threats to wood siding is the application of non-historical surface coverings such as aluminum and vinyl siding, or stucco. Application of non-historical exterior finishes results in either the removal or covering of historical materials and details. Decorative trim around doors, windows, and under rooflines is frequently removed. Detailing of the wood itself, such as beveling or beading, is also lost. Board width, length, and exposure are generally changed, thus altering the scale and appearance of the building. Artificial siding also frequently damages the fabric underneath. It can trap moisture and encourage decay and insect infestation.

In cases where artificial siding is already in place, its removal is not necessary under the guidelines. An owner may retain the material or remove it, but it need not be replaced if only minor repairs are necessary. If, however, more than 50% of the material needs to be repaired or removed, it must be replaced with historically appropriate materials.

In the case of original asbestos or masonite siding, if its removal is required, masonry, wood, or cement fiberboard siding is an appropriate replacement.

C. GUIDELINES

1. Masonry features that are important to defining the overall historical character of the building such as walls, brackets, railings, cornices, door pediments, steps, and columns, as well as joint and unit size, tooling, and bonding patterns, coatings, and color should be identified, retained and preserved.
2. Masonry surfaces should be cleaned by the gentlest method possible, such as water and detergents and natural bristle brushes. Sandblasting is prohibited.
3. Wooden materials and features to be retained include siding, cornices, brackets, soffits, fascia, window architrave, and doorway pediments. These are essential components of a building's appearance and architectural style which should not be obscured or otherwise covered.
4. Repair or replacement of deteriorated material must duplicate the original in size, shape, and texture as closely as possible. Original characteristics such as board width, length, exposure, and trim detailing when selecting a replacement material should be considered.
5. Artificial replacement siding over wood or brick is not permitted.
6. Where a structure has asbestos or masonite as original siding, it may be replaced with wood, brick, or cement fiberboard.

6. PORCHES

A. PRINCIPLES

Porches serve as a covered entrance to buildings and a transitional space between the interior and exterior and are an important design feature. They are often the principal location for ornamentation and detailing, such as brackets, posts and columns, and balustrades. Size, style, ornateness or simplicity, sense of openness, and detailing are important attributes of porches. Such features should be preserved during the course of rehabilitating a building.

Because they are open to the elements, porches also require frequent maintenance and repair. Deteriorated porch features should be repaired rather than replaced. If replacement proves necessary, replacement features and materials should approximate the originals as closely as possible. If wholesale replacement is required, the new porch should be rebuilt based on historical research and physical evidence. If a porch or individual features of it are missing and no documentation or physical evidence is available, a new porch design that is compatible with the scale, design, and materials of the remainder of the building is appropriate. Missing or deteriorated features may be replaced with compatible ones found on similar structures in the district.


Owners are often tempted to enclose porches for additional year-round living space. Although porch enclosures are generally not recommended, they can be done in an appropriate manner. Transparent materials, such as clear glass enclosures or screens that are set behind balustrade and structural systems and maintain the visual openness of a porch are permitted.




Stoops are a common feature in Seminary Ridge, these are generally uncovered, raised platforms with concrete floors, sometimes with a railing or balustrade, and are often found on the front sides of the buildings. They are generally the same height as the threshold of the front door and have a set of brick or concrete steps down to the front yard.

B. GUIDELINES

1. Porches and steps that are appropriate to a building should be retained.
2. If replacing deteriorated or missing features, it is appropriate to use other homes of the same style and period for the design of the new feature, as long as it is compatible with the structure.
3. If enclosures are undertaken, maintain the openness of porches through the use of transparent materials such as glass or screens. Place enclosures behind significant detailing, so that the detailing is not obscured. Designs for front porch enclosures which alter the visual massing and volume of the building are prohibited.
4. Stoops on facades shall not be enclosed.





SECTION VIII: DRIVEWAYS AND PARKING AREAS

The city ordinance (Section 17-674) covers driveways and parking areas and is included here.

Criteria for review of driveways and vehicular parking areas. The DDRC, in their review of all construction or alteration of driveways or other vehicular parking areas in residentially zoned DP districts located in the front or secondary front yard, shall use criteria which includes, but is not limited to the following:

- (1) Unless a showing of extraordinary and exceptional conditions pertaining to the piece of property can be shown, the amount of allowable area paved for the use of a driveway or a vehicular parking area shall be limited to a width of (12) feet measured with a straight line that runs parallel to the front or secondary front lot line.
 - (2) The designated vehicular parking area or driveway shall be placed so as to minimize its visual impact on the primary structure.
 - (3) Driveways and vehicular parking areas shall be compatible with the existing building and the site and setting of the historic district, taking into account the level of designation. Appropriate materials in an architectural conservation district are: Brick pavers, cobblestones, granite and concrete.
- NOT in Ordinance:** (4) If a parcel is commercially zoned and a parking lot is desired, parking shall not occur in the front yard. Parking shall be placed to minimize its impact on the associated structure. Parking lots must be surfaced with acceptable materials for paving in the historic district and any buffer walls or site improvements are subject to review for design and materials. Surface parking must be placed at 15' or more from a street right-of-way. Screening shall be required between a parking lot edge and a street right-of-way. Lighting must be appropriate for the residential and historic district in which the parking lot is located.



SECTION IX: BUSINESS SIGNAGE

Business Signage

Definition

Sign, business means any sign which relates in its subject matter to the buildings, businesses, establishments, occupants, uses, functions, or premises on which it is located, or to products, accommodations, services or activities offered, sold or engaged in or on the premises on which it is located. Mobile signs and portable signs may be business signs, but billboards or advertising signs are not business signs.

A. Principles:

In a residential area with the possibility of once residential properties being converted into commercial businesses, signage can have a great impact on nearby residential properties. Proper sizing, style, materials, location, and illumination will influence not only how effective a sign is for its associated business, but also its impact on the greater community.

The following guidelines do not supersede the Columbia Sign Ordinance. All signs must comply with the regulations contained in the Code of Ordinances, Columbia, South Carolina; Chapter 17, Planning, Land Development and Zoning, Divisions 12, Signs.

B. Guidelines:

Color: Limit total number of colors to increase legibility. Sign colors should complement the colors used on the structures and the project as a whole. Advertising signs should not be painted directly over brick facades.

Materials: The following materials are recommended for signage in the Seminary Ridge Neighborhood:

- Wood (carved, sandblasted, etched, and properly sealed and painted, or stained)
- Metal (formed, etched, cast, engraved, and properly primed and painted or factory coated to prevent corrosion);
- High density pre-formed foam or similar material. New materials may be appropriate if properly designed in a manner consistent with these guidelines, and painted or otherwise finished to complement the architecture.

Legibility:

Keep the message brief for greatest legibility and effectiveness. Evaluate each word and remove any words that do not contribute directly to the basic message of the sign.

Do not space words or letters too closely together; likewise, limit the number of lettering styles to increase legibility. Glossy finishes which could cause glare should be avoided.

Location:

Wall signs: signs should be placed consistent with the building's proportions and scale of elements. They should be located where architectural features or details suggest a location, size or shape for the sign. Signs should not obscure or interrupt existing architectural elements.

Ground mounted signs should be low and should not impede any sight triangles. Monument signs as well as signs hanging from a wrought iron or wood post would be appropriate. These signs should be placed far enough back from the front property line to be properly associated with the structure in which the business resides.

Window signs (such as vinyl lettering on glass) should not be used in a primarily residential historic district.

Illumination: Consider first whether the sign needs to be lighted at all, particularly in a primarily residential neighborhood. Nearby street lights may provide ample illumination.

If the sign can be illuminated by an indirect source of light, this is usually the best arrangement because the sign will appear to be better integrated into the building's architecture. A light fixture mounted on the building may provide adequate lighting. A flood light installed at ground level and directed up is appropriate for a stand alone sign.

SECTION X: ENERGY EFFICIENCY AND HISTORIC BUILDINGS

Just because you live in a charming old house does not mean you have to suffer through high energy bills or uncomfortable rooms. Historic houses have a lot of great features that were designed to take advantage of passive energy measures, like operable windows that were aligned for cross-ventilation, porches, thick materials like plaster and brick which help retain the interior temperature, and they often have mature deciduous trees around that help block the summer sun but allow the warmth in during winter months.

A variety of published studies indicate that historic homes can be as efficient as newly constructed buildings. Did you know that weatherstripping a well-maintained historic window and adding a storm window can cost less than half the price of a new window but match the energy savings? Insulating in your attic and under the first floor is one of the best ways to stop energy loss in the building, and simple tricks like caulking around windows, doors and plumbing holes, adding weatherstripping to windows, doors and your attic hatch, which is a big energy loss for buildings.

In an effort to help you enjoy your old home, these guidelines do not review energy saving measures like shutters, storm windows, storm doors or any weatherstripping. Any interior treatments such as cellular shades, reflective roll shades, thermal drapes, or interior shutters are also not reviewed.

SECTION XI: RELOCATION

A. Principles

1. Much of a building's value is in its context: the street on which it sits, the buildings that surround it, the landscape. Therefore a building should remain in its context unless its existence is threatened by encroachment or it cannot be preserved in the original location.
2. Moving a historic building from its original site should not occur.
3. Moving a non-historic building, or a building, which has irretrievably lost its architectural and historical integrity, may be appropriate.
4. Moving a building into the district is permitted if it is compatible with the district.

B. Guidelines

1. Moving a building into the district is permitted if the building will be compatible with the historic buildings surrounding the new location in terms of height, scale, setback, and rhythm of spacing, materials, texture, details, roof shape, orientation, and proportion and rhythm of openings.
2. Moving a building out of the district is not permitted unless the building does not contribute to the district's historical or architectural significance, or has irretrievably lost its architectural and historical integrity.

SECTION XII: DEMOLITION

A. Principles

The demolition of an historic building should be an action of last resort. When a structure is demolished, the community loses a part of its history, which cannot be replaced. When a house is removed and not replaced, the fabric of the neighborhood is undermined. Accordingly, such requests are reviewed very deliberately and require detailed information. Additionally, the removal of a structure without a replacement should be permitted in only the most extreme of circumstances and when all other options have been exhausted.

B. Criteria for Review *Reprinted from Code of Ordinances for City of Columbia & Rules & Regulations of Design/Development Review Commission.*

1. The historic or architectural significance of a building, structure, or object;

2. A determination of whether the subject property is capable of earning a reasonable economic return on its value without the demolition, consideration being given to economic impact to property owner of subject property;
3. The importance of the building, structure, or object to the ambience of a district;
4. Whether the building, structure, or object is one of the last remaining examples of its kind in the neighborhood, city or region;
5. Whether there are definite plans for the reuse of the property if the proposed demolition is carried out, and what the effect of those plans on the character of the surrounding area would be;
6. The existing structural condition, history of maintenance and use of the property, whether it endangers public safety, and whether the city is requiring its demolition;
7. Whether the building or structure is able to be relocated, and if a site for relocation is available; and
8. Whether the building or structure is under orders from the city to be demolished, and this criteria shall be given more significance than the above-mentioned criteria.

C. Types of Information *In addressing each of the demolition criteria the D/DRC may require the following types of information:*

1. Estimate of the cost of demolition, and estimate of the cost of renovation;
2. Report from an engineer, architect, or contractor as to the structure(s) on the property and their suitability for rehabilitation;
3. Estimated market value of the property in its current condition; after demolition, after renovation of the existing property for continued use, with proposed redevelopment;
4. Estimate from an architect, developer, real estate consultant, appraiser, or other real estate professional experienced in rehabilitation or reuse of the existing structure(s) on the property;
5. Information on any current negotiations to buy, rent, or lease property;
6. All appraisals obtained within the previous two (2) years by the owner or applicant in connection with the purchase, financing or ownership of the property;

D. Except in the case where a structure poses an extreme life-safety hazard, the demolition of a structure shall not be approved until the plans for its replacement have been reviewed and approved by the Design/Development Review Commission

SECTION XII: DEFINITIONS

Please also see the Land Development ordinance for additional definitions.

Addition: 1. Construction that increases the living or working space of an existing structure, and is capable of being mechanically heated or cooled. (*ex. porch enclosures, room additions, etc.*) 2. An alteration that changes the exterior height of any portion of an existing building. 3. Any extension of the footprint of the structure, including porches and decks.

Appropriate: Suitable for, or compatible with, a structure or district, based upon accepted standards and techniques for historic preservation and urban design as set forth in the Secretary of the Interior's Standards and these guidelines.

Architectural feature/element: Any of the component parts that comprise the exterior of a building, structure or object that convey the style of a building. (*ex. Victorian, Bungalow, etc...*)

Character-defining feature: a detail or part of a structure that imparts style or design and distinguishes it from other structures (*ex. porch railings, decorative windows*)

Compatible: to conform or be in harmony with the components of the style of a building or the character of a district.

Contributing (building/structure/site): A building, structure or site that reinforces the visual integrity or interpretability of a historic district. A contributing building is not necessarily "historic" (50 years old or older). A contributing building may lack individual distinction but add to the historic district's status as a significant and distinguishable entity.

Demolition: Active deconstruction in whole or in part of a building, object, or site.

Elevation: 1. Height in terms of distance from grade; 2. an exterior wall of a building, usually used in referring to portions other than the façade.

Enclosure: To close off a previously exterior open space, through the installation of walls or other devices.

Exterior Change: An action that would alter the appearance of a structure. Examples include: change in roof pitch or form, or replacing or covering exterior siding with substitute material, reducing, enlarging, closing or relocating window or door openings

Façade: An exterior side of a building; usually the front elevation of the building.

General maintenance and repair: Work meant to remedy damage due to deterioration of a structure or its appurtenances or general wear and tear, which will involve no change in materials, dimensions, design, configuration, color, texture or visual appearance.

Major: Substantive; substantial; as in considerable amount of.

Muntin: The strips of the window that divide the glass into panes or lights.

Mullion: The vertical divider between two windows

New Construction: The construction of any freestanding structure on a lot that ordinarily requires a permit. This may apply to a variety of activities such as storage buildings, carports & garages, secondary dwellings, etc.

Non-contributing (building/ structure/site) A building, structure or site which no longer reinforces the visual integrity of the district either because it is a vacant parcel, it is a structure that was built outside of the period of significance of the district (and does not appear similar to those within the period of significance) or it is an historic structure that has lost its architectural integrity.

Period of Significance: **a.** For an individual structure: the date of construction plus or minus ten years; **b** for a district, the span of time from the date of the oldest building within the boundaries to the date by which significant development ended.

Secondary Front Yard: The non-primary side of a building on a corner lot.

Shall: What must happen.

Should: What must happen unless evidence is presented to illustrate why an alternative is more suitable.